

HG2 INSTALLATION GUIDE

Tahoe, Yukon & Suburban 2015-2018
Rear Z-Drive® Step Pad Bumper



STEP 1:

Start by taping off the surrounding edges of the vehicle and gathering any tools you may need.

Remove the factory bumper by inserting a Phillips head screwdriver into each



STEP 2:

Feed wires through center hole, (counting 6 holes in from each side).

Remove red tape, insert HG2 bumper and apply pressure on each side.



WIRING DIAGRAM

Chassis Ground: Connect to a scraped (bare) metal surface in the driver kick panel. NEVER connect to dash brackets or at the same point as other components.

12v Constant Power: Remove the in-line fuse before connecting to a wire that has (+)12v at all times.

: Remove the in-line fuse before connecting to a wire that has (+)12v at all times.

12v Constant Power: Remove the in-line fuse before connecting to a wire that has (+)12v at all times.

12v Constant Power: Remove the in-line fuse before connecting to a wire that has (+)12v at all times.

12v Constant Power: Remove the in-line fuse before connecting to a wire that has (+)12v at all times.

12v Constant Power: Remove the in-line fuse before connecting to a wire that has (+)12v at all times.

12v Constant Power: Remove the in-line fuse before connecting to a wire that has (+)12v at all times.

BLACK (-) Chassis Ground

RED (+) 12V Constant Power

WHITE (+) Switched Power

BROWN (+) Takedown Power

GREEN (+) Cruise Mode

BLUE (+) Momentary Pattern

YELLOW (+) Right Directional

ORANGE (+) Left Directional



THANK

YOU



If you have any questions or concerns,
please reach out to us at 866.468.4569.

THANK YOU.