




HG2 RUNNER®

Runner Platform Module [RPM12]:



PARTS LIST

- 1 - RPM12 Runner Platform Module
- 1 - Pattern Selector Button
- 1 - 10A Fuse
- 1 - Installation Guide and Warranty Info Packet

REQUIRED TOOLS

- Drill
- 9/32" Drill Bit
- Wire Strippers
- Soldering Iron / Solder
- Heat Shrink Tubing
- Wire/Cable Ties

Additional tools may be required to complete installation.

INSTALLATION

Preparation

1. Read the installation guide for this product in its entirety.
2. Unpack product components and review parts list.
3. Bench test Runner Platform Module and HG2 Runner(s) using 12v power supply to ensure components are in working order.
4. **Disconnect negative terminal** from vehicle battery.
5. Prepare mounting location by removing interior panels as necessary.

Mounting

6. Mount the Runner Platform Module in a secure, dry location (interior of the vehicle). Keep away from moving parts, heat sources or locations that interfere with safe operation of the vehicle.
7. Mount the Pattern Selector Button in an easily accessible location. Drill a 9/32" hole for mounting.

Wiring

8. All wiring connections should be soldered and protected using appropriate heat shrink tubing.

BASIC OPERATION

Demo mode

Demo mode rotates through each of up to 20 patterns every 10 seconds. To enter demo mode, press the pattern selector button and power up module (key on or power from existing switching unit). Exit demo mode by cycling power off and on again without pattern selector button depressed.

Selecting Patterns

Press pattern selector button to select a new pattern. The selected pattern is retained even after cycling power.

No more than 200 total LEDs (approximately 3 runners) can be connected to a single RPM12 Runner Platform Module. Connecting more than 200 LEDs can result in failure of the Runner Platform Module, damage to the HG2 Runners and will void the manufacturer's warranty.

