

# WIRING DIAGRAM

**Chassis Ground:** Connect to a scraped (bare) metal surface in the driver kick panel. NEVER connect to dash brackets or at the same point as other components.

**12v Constant Power:** Remove the in-line fuse before connecting to a wire that has (+)12v at all times.

**Switch On/Off:** Powers the unit on and off.

**Scene Lighting:** White lights will stay on to illuminate an entire scene.

**Cruise Mode:** White takedown lights will stay on without flashing.

**Momentary Pattern:** Pattern will only engage while the switch is pressed.

**Right Directional:** Controls the right directional signal.

**Left Directional:** Controls the left directional signal.

**BLACK** (-) Chassis Ground

**RED** (+) 12V Constant Power

**WHITE** (+) Switched Power

**BROWN** (+) Takedown Power

**GREEN** (+) Cruise Mode

**BLUE** (+) Momentary Pattern

**YELLOW** (+) Right Directional

**ORANGE** (+) Left Directional